




Quantum Precision

QP-S7

PROFESSIONAL DIGITAL SCALE



Thanks for purchasing the Quantum Precision Digital Postal Scale! This User Guide is designed to get you up and running quickly with your scale. Scales are precision instruments and require proper care and skill to get the best results. If you have questions or need support, please feel free to reach out ou customer support: acscale@163.com

What' s in the Box

Quantum Precision
Digital Postal Scale



AAA Battery * 3



RECHARGEABLE
Type-C



Tape



Key Descriptions



- Turns the scale ON and OFF.



- Changes the weighing unit.




- Zero's the scale. Also subtracts the weight of an empty container(see Tare Function).



- Lock the value on the screen

Weighing Your First Item

1. Press the  key to turn the scale on.
2. Place the item on the center of the weighing platform.
3. Take your reading from the display. You can press the  key to convert between weighing units.
4. You can press the  key to turn the scale off. Or you can set the time of auto-off to save power.



Things to Avoid



Unlevel Surfaces



Radio Frequency
Interference



High Humidity



Air Currents



Vibration



Extreme Temps

Tare Function

The Tare function allows you to subtract the weight of a container so that the display only shows the weight of the contents.



Place an empty tray or container on the platform.



Press the  key to subtract the container's weight.



Add items to the container to see their weight on the display.



NOTE: The weight of the container will subtract from the available capacity and will leave a negative value on the display once the weight is removed. Press TARE again to return the display to zero.

Auto-Off

1. Turn on the scale.
2. Press and hold  button, "0/60/180/300" will be displayed repeatedly.
3. Release the  button until the display shows the time you want. (If "0" is selected, the auto-off function will be disabled.)
4. The display will show "PASS", then turn off automatically.

***By default, the postal scale will not turn off automatically.**

Accuracy

Your scale comes calibrated from the factory and most users won't need to calibrate their scale for a long time. You should check your scale's accuracy periodically using calibration weights and perform calibration if necessary. NOTE: Only use trusted calibration weights.

Calibration




Calibration is permanent and should only be performed using accurate calibration weights that match the requirements for your scale. Do not use coins or other household items to calibrate.

1. In the power-on, press and hold  button, the screen will show "Zero", and the "5kg" will be flashed immediately.
2. Press  button to switch "kg" to "lb".
3. Press  button to decrease value, press  button to increase value.
4. Place the required weight on the weighing platform, the "PASS" will be shown on the screen.
Calibration is completed.

Hold Function

1. Turn on the scale.
2. Press  button to turn on the auto hold function.
3. Put the package on the weighing platform for 5s, the reading will be locked on the display even the package is took away.
4. Press  button again to unlock.



Specifications

QP-S7

Max Capacity	86lb/66lb/46lb
---------------------	----------------

Readability	0.1oz or 5g
--------------------	-------------

Weighing Units	g, oz, kg, lb, lb : oz
-----------------------	------------------------

Dimensions	Overall: 240 x 157 x 38 mm (LxWxH) Platform: 191 x 154 mm (LxW) Display: 54.5 x 24.5 mm (LxW)
-------------------	---

Power	3 x AAA Batteries or 5v DC
--------------	----------------------------

Warranty	2 Year Limited Warranty
-----------------	-------------------------

说明书：70x115mm
105铜版纸